

XH-DJ002

Manual Hand-Crank Lighting Lift Stand

At a glance

Working height	1.8-5.5 m
Max load	200 kg (supplier-stated)
Net weight	105 kg
Base plate	460 x 460 mm
Support legs	80 x 40 x 950 mm



Preliminary document Based on supplier data only. Verify load rating, operating method and safety instructions before use.

Before Use

- Confirm the floor is level and stable.
- Fully position and secure all support legs.
- Inspect the winch, cable and fasteners for visible damage.
- Use only suitable mounted equipment and hardware.

Use Notes

- Raise and lower the mast carefully using the hand crank.
- Keep personnel clear of the load path during adjustment.
- Do not move the stand while equipment is lifted.
- Stop operation if abnormal noise or binding occurs.

Package & Size

Packed weight: 108 kg
Package size: 186 x 46 x 60 cm
Telescopic tube: 120 / 100 / 80 / 60

Contact REDJET

Sales: info@redjetstage.com
Support: support@redjetstage.com
Phone: +86 158 1243 5100
Web: redjetstage.com